

TIME-SERT®

TIME FASTENER COMPANY
5301 unit G Longley lane
Reno Nevada 89511
(800) 423-4070 (775) 829-1026
www.timesert.com

M11x1.5 NORTH STAR 4.0/4.6 HEAD BOLT THREAD REPAIR KIT

- WARNING -


Cutting tools may shatter if broken. The wearing of safety glasses is required in the vicinity of their use.

CUTTING FLUID

A Cutting fluid is necessary for drilling and tapping. (WD40)

DRILL MOTOR

The use of a half inch drill motor is recommended for drilling.



Tools needed:

Drill fixture	66256111
Drill bushing	662J-42385-302
Alignment pin	662J-42385-303
Bolts (3)	662J-42385-503
Step drill	662J-42385-504
Tap	662J-42385-505
Insert driver	662J-42385-506
Inserts (10)	66111155
loctite	6626020
Driver oil	6626010

PART

INSTRUCTIONS

STEP 1

PLACE LARGEST HOLE IN DRILL FIXTURE OVER THE HOLE TO BE REPAIRED. PLACE BUSHING IN FIXTURE, THEN PLACE LINE UP PIN IN BUSHING TO PICK UP HOLE. DO NOT FORCE PIN INTO HOLE. USE BOLTS AND TIGHTEN TO SECURE FIXTURE IN PLACE. REMOVE LINE PIN.

STEP 2

USE A SUITABLE DRILL MOTOR AND STEP DRILL THE HOLE UNTIL THE STOP COLLAR ON THE DRILL LINES UP WITH THE TOP OF THE DRILL BUSHING. THIS WILL REQUIRE REMOVING DRILL AND BUSHING SEVERAL TIMES TO CLEAR CHIPS. CLEAN OUT ALL CHIPS.

NOTE: If drill bushing turns while drilling hole, Remove drill and drill bushing, Clean out all chips.
We recommend using a long air nozzle 6" or longer to blow out all chips.

STEP 3

TAP THROUGH THE DRILL BUSHING UNTIL THE GROOVE ON THE TAP LINES UP WITH THE TOP OF THE DRILL BUSHING. THIS WILL REQUIRE REMOVING THE TAP AND BUSHING SEVERAL TIMES TO CLEAR CHIPS. CLEAN ALL CHIPS USING BRAKE OR CONTACT CLEANER THAT WILL NOT LEAVE AN OILY RESIDUE, THE HOLE MUST BE CLEAN AND DRY. USE A FLASHLIGHT TO INSPECT THE HOLE FOR CHIPS AND CLEANLINESS.

STEP 4

REMOVE FIXTURE PLATE FOR STEP 4

USE INSERT DRIVER OIL (DO NOT USE WD40.)

OIL THE THREADS OF THE INSERT DRIVER. SCREW AN INSERT ONTO THE DRIVER, APPLY A SMALL AMOUNT OF LOCTITE ON THE BOTTOM OUTSIDE THREADS ON THE INSERT AND SCREW THE INSERT INTO THE PREPARED HOLE. WHEN THE HEAD OF THE INSERT IS SEATED THE DRIVER WILL TIGHTEN UP, USE A LITTLE MORE POWER TO SCREW THE DRIVER THROUGH THE INSERT UNTIL THE GROOVE OF THE DRIVER LINES UP WITH THE TOP OF THE BLOCK. REMOVE INSERT DRIVER REPAIR IS COMPLETE.

Please check for the latest torque specifications before assembling the engine.
Improper torque of the head can lead to thread failure.